

## IMPORTANT INSTRUCTION SHEET

Dear Customer:

This information is so important we have not only included it in our enclosed instruction booklet but we are repeating it here. These instructions must be followed each and every time you move your machine.

1. BEFORE you begin to play - Push Lever "10A" up. This action will move the Pay Off Actuator (10) from a downward sloping position to an upward sloping position. See Photo #1 below.
2. BEFORE filling your machine - Be sure Dump Lever (13) is closed by pushing the plastic part (14) left so that it locks under the Dump Lever (13). Photo #2 below shows closed position - proper for playing.
3. Be sure the Supply Tray (9) on the back of your machine always has balls in it. A minimum of 300 balls is recommended for the smoothest operation of your machine. If the Supply Tray (9) runs dry your machine will not pay off when you get a jackpot and the jackpot balls will jam in the back. The first time your machine does not pay off when you hit a jackpot - put more balls in Supply Tray (9) and the unpaid jackpot will automatically pay off. But if you wait and jackpot balls begin to collect on the back of the machine they will jam in the back.

Photo #1





Photo #2



CAREFULLY READ ALL OF THE INSTRUCTIONS PROVIDED BEFORE BEGINNING TO PLAY PACHINKO

## ANSWERS TO YOUR QUESTIONS

- KEYS** No keys are available for your Pachinko Machine. The Japanese Government policy preserves the security of the machines in use in the parlors in Japan. If you plan to build your machine into a wall cabinet, a local locksmith can change the lock for you. Or you can write to us and we will send you instructions for making the locking device inoperative.
- POWER SOURCE** We repeat our previous statement – NO POWER SOURCE IS NEEDED TO OPERATE YOUR PACHINKO MACHINE. A schematic of the electrical system of the machine is not available.
- AC Adapters to make the lights flash on when you get a jackpot are available from your local Pachinko retailer.
- REPAIR SERVICE** Only one repair station is available in the United States – our factory in Southern California. Through the years we have found that the fastest way to get your repair questions answered is to send us your instruction booklet clearly showing those parts of the machine which you do not think are operating properly. Also include a complete description of the problem you are having. Be as specific as possible. A new booklet will be returned to you with instructions on how to repair your machine.
- FACE PLATE** The face plate is not cracked or scratched. Rather, there are two protective sheets of film covering both the front and back side of the face plate. If you will follow the instructions contained in your instruction booklet and remove the protective film your plate will be clear.
- PACHINKO BALLS** A minimum of 300 balls is recommended in order to prevent jamming and possible damage to your machine. The Pachinko Machine will hold 800 Pachinko Balls. Extra balls are available from your local Pachinko Retailer.
- PACHINKO STAND** Your Pachinko Machine may topple over if some sort of feet are not attached to the bottom of the wood frame. Specially designed mar-proof feet and instructions for attachment are available from your local Pachinko retailer. We urge you to make some provision in order to prevent damage to your machine and those who might be playing with it.